



HIGH-EFFICIENCY WASHERS

ATTENTION!

PLEASE READ FOR BEST WASH PERFORMANCE




1 **LOAD** washer. Do not overload. Close door firmly.




2 **ADD** recommended amounts of detergent, bleach and fabric softener. Do not open dispenser drawer when machine is in use.

→ Too much detergent leaves residue in clothing and causes washer malfunction.



3 **DEPOSIT** coins.



4 **SELECT** fabric setting. Door will lock. Do not open.

FOR YOUR SAFETY

- Never launder items containing cooking oil, foam rubber, flammable materials or fumes.
- Never reach into the washers while they are operating.
- Never allow children to play on or around the washers.



SEBCO | LAUNDRY SYSTEMS™