

HIGH-EFFICIENCY WASHERS ATTENTION!

PLEASE READ FOR BEST WASH PERFORMANCE






bleach and fabric softener. Do not open dispenser drawer when machine is in use.

Too much detergent leaves



Too much detergent leaves residue in clothing and causes washer malfunction.





FOR YOUR SAFETY

MG11175_MHN30Sign23x40.indd 1

- Never launder items containing cooking oil, foam rubber, flammable materials or fumes.
- Never reach into the washers while they are operating.
- Never allow children to play on or around the washers.

